

STATE OF OREGON
DEPARTMENT OF GEOLOGY AND MINERAL INDUSTRIES

800 NE Oregon St #28 Portland, OR 97201

MISCELLANEOUS APPLICATION
(In compliance with rules and regulations pursuant to ORS 520)

Enerfin Resources Northwest

"Longview Fibre"

43-32-65 (Conder)

(Company or Operator)

(Lease)

(Well No.)

Sec. 32 T 6N R 5W Surveyed Coordinates:

SHL= 2,367' North and 1,009' West from the Southeast corner of Section 32

BHL=

Wildcat: NA (or) Field Name: Mist Gas County: Columbia

Date: July 22, 1999

Signature: Rob Lucas

Use this form for telephone applications to deepen, rework, abandon, or any other proposed procedure on an existing well.

This form becomes a permit when signed and dated by DOGAMI in the box below.

The present condition of the well, including complete casing record, is as follows:

Casing(s):	10-3/4" 32.75# H-40 cemented at 502' 7" 20# K-55 cemented at 1,839'	<p><i>Plug:</i> 30 SX cement on 8/11/99. calculated top 166' Tag @ 1673' ✓</p>
Perforations:	10 SPF from 1,828'-1,838' 6 SPF from 1,838'-1,843' (open hole from 1,839'-1,845')	
Tubing Detail:	60 joints of 2-7/8" 6.5# J-55 EUE hung at 1,763'	

Following is a detailed account of proposed work:

1. Set cement plug from 1,845'-1,778'.	<p><i>1845 bottom cement plug.</i></p>
2. Change hole over to drilling mud.	
3. Cut off wellhead and casings. Set cement plug from 25'-surface in 7" casing and 7" X 10-3/4" annulus as needed.	
4. Restore location as per landowner wishes.	

10 stands = 620	1056
1 joint + 31	661
10 + 10	1717
661	1655

Spacing Unit

DOGAMI approved July 22, 1999
DOGAMI will tag the cement
plug @ or above 1,778'.
24-hour notice to
DOGAMI to ~~test~~
and tag top of
cement.

49
62
98

13 stands = 26 joints in rock

338

6 Tubing

1655
1673

456
62 1046

R-43-32-65

SE 1/4 Sec. 32 T6N R5W

OIL & GAS PERMIT # 411
API #: 36-009-00302