

PLUGGING RECORD

The owner or operator of any oil or gas well or stratigraphic hole shall file this form with the Director of the State of Oregon Department of Geology and Mineral Industries setting forth in detail the method used in plugging such well. The form must be within twenty (20) days after plugging for oil and gas wells, or within sixty (60) days for stratigraphic holes.

Rule L of rules and regulations adopted pursuant to ORS 520.095 (1) (13) (Chapter 667 OL 1953)

Operator Ross R. Mitchell Field Dallas area  
Pool \_\_\_\_\_  
County Polk County

ADDRESS ALL CORRESPONDENCE CONCERNING THIS FORM TO:

Street 3898 - 7th Avenue, N.E. City Salem State Oregon

Lease Name ~~Adams-Bliven~~ 4 Well No. 4 Sec. 15 T. 8 S R. 5 W

Date well was plugged July 27 19 60.

Was the well filled with mud laden fluid, according to regulations of the Board of the State of Oregon Department of Geology and Mineral Industries? Yes

How was the mud applied? From surface. Were plugs used? Cement If so, show all shoulders for casing, depth of each, and size of casing, size and kind of plugs used, and depths placed. Also amount of cement and rock used. Use additional sheets if necessary.

**8" surface casing cemented at 50 feet with 12 sacks.**

**5" casing hung at 305 feet, grain seal around shoe. (Casing pulled upon abandonment)**

**340 Feet T.D. (For plugging details see other side.)**

Was notice given, before plugging, to all available adjoining lease and land owners?

Ross R. Mitchell  
(Operator)

AFFIDAVIT

State of Oregon  
County of Clackamas

I, Ross R. Mitchell, being duly sworn, say that I have knowledge of the facts stated herein, that they are true and correct, and that I am authorized to make this report.

Subscribed and sworn to before me this 2 day of Aug. 19 60

Notary public in and for Clackamas Co. State of Oregon

Perry J. Board

My commission expires Jan. 12, 1961

## Plugging details

1. Dumped in 10 sacks of construction cement on top of bridge at 50 feet.
2. Filled hole with mud.
3. Put in top plug - 3 sacks of construction cement.
4. Cut off casing 3 feet below ground surface.