

PLUGGING RECORD

The owner or operator of any oil or gas well or stratigraphic hole shall file this form with the Director of the State of Oregon Department of Geology and Mineral Industries setting forth in detail the method used in plugging such well. The form must be filed within twenty (20) days after plugging for oil and gas wells, or within sixty (60) days for stratigraphic holes.

Rule L of rules and regulations adopted pursuant to ORS 520.095 (1) (13) (Chapter 667 OL 1953)

Operator Miriam Oil Company Field Dallas area  
Pool \_\_\_\_\_  
County Polk

ADDRESS ALL CORRESPONDENCE CONCERNING THIS FORM TO: J. P. Thornhill

Street 126 W. 11th City McMinnville State Oregon

Lease Name Elliott (Deepening) Well No. 1 Sec. 9 T. 8 S R. 5 W

Date well was plugged July 29 1959.

Was the well filled with mud laden fluid, according to regulations of the Board of the State of Oregon Department of Geology and Mineral Industries? Yes

How was the mud applied? Left from drilling Were plugs used? Yes If so, show all shoulders left for casing, depth of each, and size of casing, size and kind of plugs used, and depths placed. Also amount of cement and rock. Use additional sheets if necessary.

8" casing cemented at 100 feet with 35 sacks.  
(1200 feet of 5" casing was pulled before plugging)

7-5/8" hole 100 feet to 1835 feet.

(See attached sheet for details of plugging.)

Was notice given, before plugging, to all available adjoining lease and land owners?

\_\_\_\_\_  
(Operator)

AFFIDAVIT

State of \_\_\_\_\_

County of \_\_\_\_\_

I, \_\_\_\_\_, being duly sworn, say that I have knowledge of the facts stated herein, that they are true and correct, and that I am authorized to make this report.

Subscribed and sworn to before me this \_\_\_\_\_ day of \_\_\_\_\_ 19\_\_\_\_

Notary public in and for \_\_\_\_\_

My commission expires \_\_\_\_\_.

(Notarization is not necessary since the work was witnessed and approved by V. C. Newton, Petroleum Engineer, State Department of Geology and Mineral Industries.)

Miriam Oil Company  
Elliott No. 1  
Permit No. 17 - Deepening

Plugging Report

1. Found salt water standing at 65 feet. Bailed salt water from 65 feet to 110 feet.
2. Drove an 8" x 2' wood plug to 110 feet, and stuffed bundle of newspapers and rags on top of it.
3. Poured in seven sacks of construction cement on top of the plug at 110 feet. Cement filled to 90 feet.
4. Stuffed empty cement sacks on top of the cement.
5. Put water and clay-loam soil in the casing (90-10 feet).
6. Put an 8" x 2' wood plug at 10 feet.
7. Poured three sacks of construction cement in the top of the 8" casing - filled to surface.

*copy*