

STATE OF OREGON  
DEPARTMENT OF GEOLOGY AND MINERAL INDUSTRIES

800 NE Oregon St #28 Portland, OR 97201

HISTORY OF OIL OR GAS WELL  
(In compliance with rules and regulations pursuant to ORS 520)

Enerfin Resources Northwest				"Longview Fibre"				31-36-65 (King)				
(Company or Operator)				(Lease)				(Well No.)				
Sec.	36	T	6N	R	5W	Surveyed Coordinates:						
SHL=	958' South and 2,450' West from the Northeast corner of Section 36											
BHL=	1,201.56' North and 816.54' West from SHL											
Wildcat:	NA	(or) Field Name:				Mist Gas	County:		Columbia			
Signature:												
Date:	August 18, 1999					Position:		Operations Manager				

Use this form in reporting the daily operations at the well. (Operator may use his own forms, but heading of this form must also be completed and submitted.) Please submit a complete history of the well. Include such information as bit sizes, mud weights, casing sizes and depths set, amount of cement used, drilling depths, fishing, logging, perforating, and plugging procedures, and anything else pertinent to the operations. Do not include lithology.

Date

- 08-12-99 MIRU Taylor workover rig and pump. Open well (345 SITP/345 SICP). Bleed pressure off well and circulate with water to assure static condition. Begin removing tree (tree bolts rusted). Secure rig and CWIFN.
- 08-13-99 Remove tree and install BOPE. Pull hangar and lower tubing tail to 1,167'. Equalize 25 sx of Class "G" cement. Pull out of hole. Wait on cement. Run in hole and locate TOC at 1,042' (witnessed and approved by Dan Wermiel-DOGAMI). Change hole over to drilling mud. Pull out of hole laying down tubing. Nipple down BOPE. Cut off wellhead and cut casings 5' below GL. Set 25 lineal foot cement plug from surface in 4-1/2" casing and 4-1/2" X 8-5/8" annulus. Rig down hoist and move equipment off location.