

HISTORY OF OIL OR GAS WELL  
(Submit in duplicate)

In compliance with rules and regulations adopted pursuant to ORS 520.095 (Chapter 667 OL 1953)

Operator **I. W. Love Drilling Company** Field **Burns area**  
Well No. **H. C. Voglar No. 1**, Sec. **25**, T. **24 S** R. **31 E** W.B. & M.Date **11/7/57** Signed **(Taken from Tour Report by V. C. Newton)**  
Title **Petrol. Eng. Dept of Geol.**  
(President, Secretary or Agent)

It is of the greatest importance to have a complete history of the well. Use this form in reporting the history of all important operations at the well, together with the dates thereof, prior to the first production. Include in your report such information as size of hole drilled to cementing or landing depth of casings, number of sacks of cement used in the plugging, number of sacks or number of feet of cement drilled out of casing, depth at which cement plugs started, and depth at which hard cement encountered. If the well was dynamited, give date, size, position and number of shots. If plugs or bridges were put in to test for water, state kind of material used, position and results of pumping or bailing.

Date | 3/21/50 to 3/23/50 | Spudded drilled to 1400 feet. Surface casing at about 500 feet?

3/24/50 | Drilled to 1572 feet. Lost circulation at 1500 feet.

3/25/50 to 4/ 1/50 | Mixing mud and lost circulation material. (Grinding up hay in mud.)

4/ 2/50 | Regained circulation at 2:00 p.m. Drilled to 1604 feet.

4/ 3/50 to 4/ 5/50 | Losing mud 1604-1808 feet. Drilled to 1808 feet.

4/ 6/50 to 4/ 9/50 | Shut down. Waiting on mud?

4/10/50 to 4/29/50 | Mixing mud. Drilled to 2603 feet. Core #1 (2220-2225), recovered sand.

4/30/50 | Drilled to 2647 feet. Twisted off drill pipe. Ran in with an overshot and pulled the fish. Continued drilling to 2779 feet.

HISTORY OF OIL OR GAS WELL  
(Submit in duplicate)

In compliance with rules and regulations adopted pursuant to ORS 520.095 (Chapter 667 OL 1953)

Operator **I. W. Love Drilling Company** Field **Burns area**  
Well No. **H. C. Voglar No. 1**, Sec. , T. R. W.B. & M.Date **Page 2** Signed  
Title  
(President, Secretary or Agent)

It is of the greatest importance to have a complete history of the well. Use this form in reporting the history of all important operations at the well, together with the dates thereof, prior to the first production. Include in your report such information as size of hole drilled to cementing or landing depth of casings, number of sacks of cement used in the plugging, number of sacks or number of feet of cement drilled out of casing, depth at which cement plugs started, and depth at which hard cement encountered. If the well was dynamited, give date, size, position and number of shots. If plugs or bridges were put in to test for water, state kind of material used, position and results of pumping or bailing.

5/ 1/50 to 5/ 5/50 | Drilled to 3603 feet. Carrying lost circulation material in the mud.

5/ 6/50 to 5/12/50 | Drilled to 3710. Lost bit in the hole. Ran in with a junk basket and pulled out the bit and about 2 cones. Continued drilling to 3753 feet.

5/13/50 to 5/14/50 | Drilled to 3992 feet. Core #2 (3992-4007), limy sand. Drilled to 4255 feet.

5/15/50 | Drilled to 4550 T.D. Ran Schlumberger electric log.